

VOGUE

Stainless Steel Midi Sink Assembly Instructions

GJ537 Midi Sink - 750 x 600 x 900mm



Safety Tips

Whilst all care has been taken to remove sharp edges, care must be taken when cleaning or handling to prevent risk of injury from exposed metal edges.

DO NOT overload the sink top or shelf causing it to bend.

Part List

	x1		x1		x1
	x4		x16		

UK	0845 146 2887	Fourth Way, Avonmouth, Bristol, BS11 8TB United Kingdom
NL	0800 – 29 1 29	
	040 – 2628080	
FR	0800 - 29 2 29 01 60 34 28 80	

DE	0800 – 1860806	
IT	N/A	
ES	901-100 133	
PT	vendas@nisbets.pt	
IE	42 North Point Business Park, New Mallow Road, Cork, Ireland	

Assembly

NOTE: Be sure to check all packaging materials for any small parts that may have come loose during transportation.

1. Remove all protective film, taking care to avoid scratching the surface.
2. Place the shelf on its side on the floor.
3. Insert the leg into the sockets situated at each corner of the shelf, lining up the socket with the line marked on the leg. **[Fig.1]**
4. Use grub screws to loosely fix the shelf to the legs, and then stand upright. **[Fig. 2,3 and 4]**
5. Position the sink top onto the legs, ensuring each leg is firmly located in its corresponding corner socket. **[Fig.5]**
6. Fix the sink top in place using the remaining grub screws. Ensure the sink top is both level and securely fixed.

NOTE: Adjust the feet if necessary to level the table.

Before using for the first time VOGUE recommend the table is cleaned thoroughly with a suitable cleaning agent. Remove all cleaning residues and dry thoroughly.

Fig.1



Fig.2



Fig.3



Fig.4



Fig.5



Cleaning

- Clean the table regularly using a cleaning agent suitable for use with stainless steel and galvanised surfaces.
- Always remove cleaning agents residues, this can discolour the surface.
- Never leave any surface damp as this may cause discoloration.